



UK MKIII Supra Owners Group

Removing the PCV System



Author	J Seaman
Date	29/08/07
Version	1.00
Edited by	NA

Disclaimer

Neither the author nor the MKIII Supra Owners Group accepts liability, including liability for negligence, in respect of any statement in this guide.

The guide reflects the opinions of the author following his own experience, and does not state any of the opinions as pure factual information, and accepts no liability for the interpretation of the report by the reader. Neither the author nor the MKIII Supra Owners Group accepts liability for the distribution of this guide, or for the actions that may occur following the guides distribution.

The guide may not be distributed without the express permission of the author

Step 1 - Go through the steps for removing the 3000 pipe

Step 2 - Squeeze the metal clip connecting the PCV system to the throttle body and work it back down the pipe so it doesn't hold the rubber hose on to the metal tube



Step 3 - Undo the jubilee clip at the other end of this pipe that connects to the accordion hose



Step 4 - Pull back the metal clips that hold the wiring for the lambda sensor in place and move the wire clear of the pipework



Step 5 - Use a spanner to undo the 12mm bolt holding the bracket for the PCV pipe in place. Be careful not to drop the bolt, undo the last bit with your fingers



Step 6 - Retract the metal spring clips up the rubber hose for both the cam cover breathers. You want to pull the rubber hose away with the pipework rather than leaving them connected to the cam covers



Step 7 - Pull the pipework free from the vehicle

