



UK MKIII Supra Owners Group

## Adjusting the HKS SSQBOV



Author	J Seaman
Date	29/08/07
Version	1.00
Edited by	NA

## Disclaimer

Neither the author nor the MKIII Supra Owners Group accepts liability, including liability for negligence, in respect of any statement in this guide.

The guide reflects the opinions of the author following his own experience, and does not state any of the opinions as pure factual information, and accepts no liability for the interpretation of the report by the reader. Neither the author nor the MKIII Supra Owners Group accepts liability for the distribution of this guide, or for the actions that may occur following the guides distribution.

The guide may not be distributed without the express permission of the author

Adjusting the HKS SSQBOV is a very simple task, all you do is:

Step 1 - Looking at the back of the dump valve, you will see two nuts (See picture)



Step 2 - Slacken the nut closest to the BOV body



Step 3 - Either unscrew or tighten the rear nut (furthest from the BOV body). For the 7MGTE, apparently the valve is best at the fully tightened position



Step 4 - Once you have chosen the correct position, tighten up the nut closest to the valve to lock the other one in place. For my car I wanted both nuts right next to the BOV body so I simply screwed the rear nut all the way in

